


RESET YOUR TELECARE UNIT

How to reset your TELECARE:
On the left hand side of the unit there is a swit



USING A PEN slide the switch to the O (off) position. And wait 30 seconds.

NOW slide the switch back to the I (on) position.




This light will flash **RED** for a few minutes then go off. If it stays on **RED** it indicates NO SIGNAL. Please report this to reception.



This light will flash **GREEN** for a few minutes, this is normal, it indicates the battery is charging.

RESET YOUR TELECARE UNIT

How to reset your TELECARE:
On the left hand side of the unit there is a swit



USING A PEN slide the switch to the O (off) position. And wait 30 seconds.

NOW slide the switch back to the I (on) position.



This light will flash **RED** for a few minutes then go off. If it stays on **RED** it indicates NO SIGNAL. Please report this to reception.



This light will flash **GREEN** for a few minutes, this is normal, it indicates the battery is charging.